FIG. 1A




FIG. 1B




FIG. 2





FIG. 3



p: Normalized transmitted power

P:Total power

 $P_0$ : Average power

θ: Modulation signal

 $\gamma$ : Modulation efficiency

 $V_0$ : Bias Voltage

$$b_3 = -\gamma^2 b_1^3 a_3 \quad \text{and} \quad$$

$$b_5 = \gamma^4 b_1^5 (3a_3^2 - a_5)$$




FIG. 4B




FIG. 5A




FIG. 5B




FIG. 6A




FIG. 6B




FIG. 7A




FIG. 7B




FIG. 8A




FIG. 8B

